



# HP G60 RAM Replacement

Upgrade your RAM for boost the speed of your computer

Written By: jimenezser






## PARTS:

- [PC2-5300 2 GB RAM Chip](#) (1)
-



## Step 1 — Battery





- First, you should to remove the battery to avoid electric shocks
- Slide and unlock the battery, then, lift it

## Step 2 — RAM cover




- Remove the two screws with a not too large screwdriver
- Now lift the cover, the screws are part of the cover

## Step 3 — Eject RAM



- Push the little aluminum locks at the top and the bottom of the ram
- The memory will lift, then pull it
- Make this with the another RAM slot


## Step 4 — New RAM



- The new RAM memory should to be insert in a 45 degrees angle
- Then, push it and the memory will lock by itself
- Make this with the second memory



## Step 5 — RAM cover (Again)



- Insert the cover from right to left, then, screw it
- If cover is lifted, press it softly and secure it

---

This document was last generated on 2017-06-17 06:38:13 AM.